

DEPARTMENT OF MECHANICAL ENGINEERING LAB MANUAL

SUBJECT: AUTOMOBILE ENGINEERING

B.TECH- 5th Semester BRANCH: - ME



**KCT COLLEGE OF ENGG & TECH,
FATEHGARH**


Punjab Technical University

LIST OF EXPERIMENTS

1. Valve refacing and valve seat grinding and checking for leakage of valves
2. Trouble shooting in cooling system of an automotive vehicle
3. Trouble shooting in the ignition system, setting of contact breaker points and spark plug gap
4. Demonstration of steering system and measurement of steering geometry angles and their impact on vehicle performance.
5. Trouble shooting in braking system with specific reference to master cylinder, brake shoes, overhauling of system and the adjusting of the system and its testing.
6. Fault diagnosis in transmission system including clutches, gear box assembly and differential.
7. Replacing of ring and studying the method of replacing piston after repair.

EXPERIMENT NO 1

OBJECTIVE -Valve refacing and valve seat grinding and checking of leakage of valves



THEORY


Each cylinder has two valves, an intake and exhaust valve. Some high-performance engines have four valves per cylinder- two intake and two exhaust valves. Usually, the intake valve is larger than the exhaust valve. The reason is that when the intake valve is opened, the only force moving air-fuel mixture into the cylinder is atmospheric pressure. When the exhaust valve is opened, the piston is moving up, and there is a high pressure driving the exhaust gases out. Therefore, the intake port must be larger to allow enough air-fuel mixture to enter. Various types of valves have been used in the past. But the valve in general use today is mushroom, or poppet, valve. When the valve is closed, it is held on the valve seat by the valve spring.

PROCEDURE

VALVE REFACING: If the valves are good enough to reuse, is to reface them. This requires a valve-refacing machine. The valve refacer has a grinding wheel, a coolant delivery system, and a chuck, which holds the valve for grinding. Set the chuck to grind the valve face at the specified angle. This angle must just match the valve seat angle, or make an interference angle of $\frac{1}{2}$ to 1 degree. Then put the valve into the chuck and tighten the chuck. The valve should be placed in the chuck so that the part of the stem that runs in the valve guide is gripped by the chuck. To start the operation, align the coolant feed so that it sprays coolant on the rotating valve face. Then start the machine. Move the lever to carry the valve face across the grinding wheel. The first cut should be a light one. If this cut removes metal from only one-half or one-third of the face, the valve may not be centered in the chuck. Or the valve stem is bent, and the valve should be discarded. Cuts after the first should remove only enough metal to true the surface and remove pits. Do not take heavy cuts. If so much metal must be removed that the margin is lost, discard the valve. Loss of the margin causes the valve to run hot. Then it will soon fail. Follow the operating instructions of the valve-refacer manufacturer. Dress the grinding wheel as necessary with the diamond-tipped dressing tool. As the tool is moved across the rotating face of the grinding wheel, the diamond cleans and aligns the grinding face.


VALVE SEAT GRINDING:- For effective valve seating and sealing, the valve face must be concentric with the valve stem. Also, the valve guide must be concentric with the valve face. In addition, the valve face angle must match the valve seat angle (or have an interference angle). Therefore, as a first step in valve seat service, the valve guides must be cleaned and serviced. (Using a dial indicating valve guide gauge to check for wear. Movement of the probe in and out of the guide will cause the needle to move if the guide is irregularly worn.)

The valve seats are of two types, the integral type and the insert type. Replacing seat inserts and grinding seats are described below.



1. Replacing valve seat inserts: - A valve -seat insert may be badly worn. Or it may have been refinished previously so that there is insufficient metal. With either condition, the seat must be replaced the old seat must be removed with a special puller. If the puller is not available, the insert is punch marked on two opposite sides. An electric drill is then used to drill holes almost through the insert. Then, a chisel and hammer can be used to break the insert into two halves so it can be removed. Care must be taken so that the counter bore isn't damaged. If the new insert fits too loosely, the counter bore must be re-bored over size. Then an over size insert installed. It may be necessary to chill the seat and heat the head before the seat is driven into place. After installation, the valve seat should be ground

2. Grinding valve seats: -



The valve seat grinder rotates a grinding stone of proper shape on the valve seat. A pilot installed in the valve guide keeps the stone concentric with the valve seat. This means that the valve guide must be cleaned and serviced before the seat is ground. In the seat grinder the stone is automatically lifted about once a revolution. This permits the stone to clear it self of grit and dust by centrifugal force. After the seat is ground, it may too wide. Narrow the seat by using upper and lower grinding stones to grind away the upper and lower edges of the seat. If the seat is too high, grinding with the 150 stone may lower it. A steel scale can be used to measure seat width. When a new valve is installed, it may sit too high above the seat. Then grind the seat slightly with a stone of the same seat angle. This will lower the valve further into the seat, and raised the seat contact on the valve face.

AUTOMOBILE ENGG.

Many shops are now using a hand operated carbide cutter. This device takes the place of motor driven stones in refinishing the valve seats.

Checking of leakage of valves:-


1. Check valve guides for wear. Clean, replace or and ream for same size valve stem if necessary. Or ream for a larger diameter valve stem.
2. Check valves and valve seats. Clean valve heads and stems on a wire wheel.
3. Refinish valve seats, and reface valves as necessary. Check valve seating. Refinishing valve-stem ends if necessary.
4. Check rocker arms for wear. Service or replace as necessary.
5. Replace valves and springs in head.
6. Check and adjust valve clearance as necessary.

EXPERIMENT NO 2


OBJECTIVE: - Troubleshooting in cooling system of an automotive vehicle.

Theory: The purpose of cooling system is to keep the engine at its most efficient operating temperature at all speeds & under all operating conditions. During the combustion of the air fuel mixture in the engine cylinders, temperatures of 2200°C or higher may be reached by the burning gases. The cylinder walls, cylinder head & pistons absorb some of this heat. They, in turn, must be provided with some means of cooling so that they do not get hot.

Cylinder wall temperature must not go higher than about 205°C to 260°C Temperature higher than this causes the lubricating oil film to break down & loose its lubricating properties. However, the engine operates best at temperatures as close to the limits imposed by oil properties as possible. Removing too much heat through cylinder walls & head lowers the thermal efficiency of the engine. Cooling systems are designed to remove about one-third (30-35%) of the heat produced in the combustion chambers by the burning of the air-fuel mixture The engine is very inefficient when cold. Therefore, the cooling system includes devices that prevent normal cooling action during engine warm-up. These devices allow the engine parts to reach their normal operating temperatures more quickly. This shortens the inefficient cold operating time. When the engine reaches its normal operating temperature, the cooling system begins to function. The cooling system removes excess heat when the engine is hot & slowly or not at all when the engine is cold or warming up.



Cooling system



Main Parts of Cooling System: *

Radiator: It cools off coolant (it is an anti-freeze mixture) by allowing air passing through the area to dissipate the heat generated by the engine.

Pump: It draws the coolant from the radiator & pumps it through the engine block cylinder heads heater core & back to the radiator.

AUTOMOBILE ENGG.

Freeze plugs: It is actually a steel plug designed to seal holes in the engine block & cylinder head created from the casting process. In freezing weather, they may push out if there is not enough anti-freeze protection.

Head gasket: It seals the major parts of the engine to prevent oil, anti-freeze mixture and cylinder pressure from mixing together.

Heater Core: It provides heat to the interior of the core by using heat removed from the anti-freeze & flown in by the blower motor, may cause steam, odd or actual dripping inside the car when it leaks.

Thermostat: It controls the minimum operating temperature of the engine. The thermostat is closed when the engine is cold, in order to speed the warming-up & opens when normal operating temperature has been reached, to allow the anti-freeze to pass through the radiator.

Hoses: These connect the other main components of the cooling system. Hose manufacturers recommend replacing every 4 years regardless of apparatus because there may be deterioration of the inside of the hose which cannot be seen.

Fan clutch: It senses the temperature of the air coming through the radiator & either slips or binds up to the pull required amount of air through the radiator.

Electric cooling fan: Most front wheel cars use an electric cooling fan because of the transverse mounted engine. It is turned on by a system of sensors & relays when the engine reaches about 230°F & stays on until it is cooled to about 200°F.

Cooling System Trouble Diagnosis:

Three major cooling system complaints are:

- Loss of Coolant
- Engine overheating
- Slow warm up

Explanation:

Causes of loss of coolant: Many gaps can be spotted easily for two reasons. One - the cooling system requires frequent refilling. Two - the point of gap can be usually found at the top of a telltale stain. Dye is added to most anti-freeze to make gap detection easier.

There are two types of coolant gaps. External gaps are those, where the coolant can drip into the ground. These can be seen. Typical leak points from hose & hose connections, heater core, radiator core & expansion core plugs (freeze plugs) in the block & head.

Internal leaks can severely damage the engine. The coolant may contaminate the oil & may cause rust. A coolant leak into the combustion chamber while the engine is stopped may fill the combustion chamber. If the leak is from the radiator, it should either be removed or replaced. Oil in the coolant indicates leakage of transmission oil cooler in the outlet tank of the radiator. If the leak is at the hose connections, the hose should be replaced.

Condition	Possible cause	Check or correction
Loss of coolant	Pressure cap and gasket defective	Inspect. Wash gasket and test. Replace only if cap will not hold pressure specified.
	Leakage	Pressure test system
	External leakage	Inspect hose, hose connections, radiator, edges of cooling system, gaskets, core plugs, drain plugs, oil-cooler lines, water pump, expansion tank and hoses, heater-system components. Repair or replace as required
	Internal leakage	Check torque of head bolts, retorque if necessary. Disassembly engine as necessary. Check for cracked intake manifold, blown head gasket, cracked cylinder head or engine

Causes of engine overheating: The driver may notice that the red light stays on or the temperature gauge registers in the overheating zone. Also, the driver may complain that the engine boiled over Possible causes of engine overheating include

- 1 Lower coolant level caused by leakage of coolant.
- 2 Accumulation of rust & scale in the system, which prevents normal circulation of coolant. Anti-freeze compounds contain additives which tend to prevent the formation of rust & corrosion
3. Collapsed hoses which prevent normal coolant circulation. Suction hoses should contain a spring to prevent collapsing
4. Defective thermostat which does not open normally blocking circulation of coolant. If the engine overheats without the radiator becoming normally, warm & if the fan belt is properly tightened. Then the thermostat is properly at fault*
Sometimes, on some cars, grains of sand from the sand core for the engine block or head may lodge in the thermostat, preventing it from opening. A thermostat that is installed backwards usually cannot open & will also cause overheating.
5. A loose or worn fan belt will not drive the water pump fast enough. The belt should be tightened or replaced. Where a pair of belts is used, both belts should be replaced at the same time, not just one belt that appears most worn. When you replace only one belt, the

entire load is on new belt. It will wear rapidly. When both the belts are replaced with a none matched pair, and then each belt will carry half the load.

6. Overheating may be caused by after boil. This may occur when the coolant starts boil after the engine has been turned off. For example, after a long hard drive, engine has too much heat in it, that when the water pump stops circulating coolant, it starts to boil.

Condition	Possible cause	Check or correction
Engine overheating	Low coolant level	Fill as required. Check for coolant loss.
	loose fan belts Pressure cap defective	Adjust Test. Replace if necessary.
	Radiator or air-conditioner condenser obstructed Thermostat stuck closed	Remove bugs, leaves, and debris. Test. Replace if necessary..
	Fan drive clutch defective	Test. Replace if necessary
	Ignition faulty	Check timing and advance. Adjust as required.
	Temperature gauge or HOT light defective	Check electric circuits. Repair as Required
	Inadequate coolant flow Exhaust system restricted	Check water pump and block for blockage
		Check with restrictions

Causes of slow warm-up: The most likely cause of slow warm-up is a thermostat that is struck open. This allows the coolant to circulate between the engine & the radiator even though the engine is cold. Therefore, the engine has to run longer to reach normal operating temperature. As a result, engine wear is greater because the engine operates cold for a longer time.

Another possible cause of slow warm-up is that the thermostat has been removed. Never remove the thermostat & leave it out of cooling system. This does not improve coolant circulation. It does delay warm-up & increase engine wear & sludge formation.

A quick check for a missing or struck open thermostat can be made by squeezing the upper hose immediately after starting the cold engine. Keep your hand away from the fan. No coolant flow through the upper hose should be felt if you feel movement, the thermostat is missing or open

condition	Possible Causes	Check or Correction
Slow warm up	Open or missing thermostat	Test replace or install necessary

	Defective temperature gauge	Check electric Circuit
--	-----------------------------	------------------------

Working safely on Cooling System: There are several safety hazards one must watch for, when working on engine & the cooling system:

1. Keep your hands away from the moving fan. When the engine is running, the fan is turning so fast it is a blur. But it can mangle your hand and cut-off fingers, if the hand gets into the fan.
2. Never stand in a direct line with the fan. A fan blade could break off & fly out from the engine compartment. Any person standing in line with the fan could be injured or killed. Before starting the engine, examine the fan for cracked or loose blades. If you find any damage the fan must be replaced.
3. Keep the fingers away from the moving belt & pulleys. The fingers could be pinched & cut-off if they are caught between the belt and the pulley
4. Never attempt to remove the radiator cap from the cooling system of an engine that is near or above its normal operating temperature. Releasing the pressure may cause instant boiling of the coolant.
5. Coolant is poisonous:- It can cause serious illness or even death if it is swallowed. Always wash your hands thoroughly, if you get coolant on them.

EXPERIMENT NO 3**OBJECTIVE:**

Trouble shooting in the ignition system, setting of contact breaker points and spark plug gap


THEORY:

The basic difference between the contact-point and the electronic ignition systems is in the primary circuit. The primary circuit on the contact-point system is opened and closed by contact points. In the electronic system, the primary circuit is opened and closed by the electronic control unit (ECU).

The secondary circuits are practically the same for the two systems. The difference is that the distributor, ignition coil, and the wiring are altered to handle the higher voltage that the electronic ignition system produces.

One advantage of this higher voltage -upto-47,000 volts- is that spark plugs with wider gaps can be used. This results in a longer spark which can ignite leaner air-fuel mixtures. As a result, engines can run on leaner air-fuel mixtures for better fuel economy and lower emissions.

Another difference is that some electronic ignition systems have no mechanical advantage mechanisms -centrifugal or vacuum. Instead, the spark timing is adjusted electronically.

**DIAGRAM:****Trouble shooting in ignition system**

Ignition- system quick check: Several checks have been used in the past to help locate the cause of various troubles for e.g. one test is the spark test. Remove a cable from spark plug, insert plug extender into the cable end, and hold the extender into about 3/8" (10mm) from the engine block with insulated pliers. Crank the engine and check for sparking. If no sparking occurs, there is trouble in the ignition system. If there is good spark, the failure to start is probably in the fuel system. This test is not recommended for all electronic ignition systems.

Engine cranks normally but fails to start: There is no spark during the spark test, if the oscilloscope fails to show a secondary voltage pattern there are several possible causes:

If you get a good spark, the ignition primary and secondary circuits probably are ok. The failure to start could be due to fouled spark plugs or out of time ignition. However failure to start with a good spark is more likely due to trouble in the fuel system.

Condition	Possible Causes	Check or correction
Engine cranks normally but fails to start	No voltage to ignition system	Check battery, ignition switch, wiring
	ECU ground lead open, loose or corroded	Repair as needed
	Ignition coil open or shorted	Test coil, replace if defective.
	ECU faulty	Replace
	Damaged armature or sensor	Replace damaged part
	Defective distributor cap or rotor	Replace defective part

Engine backfires but fails to start: This can be caused by ignition or valve timing that is considerably off by faulty or wet distributor cup or rotor that allows high voltage leakage from one terminal to another or by high voltage cables being incorrectly connected .

Condition	Possible Causes	Check or correction
Engine backfires but fails to start	Incorrect timing	Check and adjust timing
	Moisture in distributor cap	Dry cap
	Cap faulty- voltage leakage across carbon paths	Replace cap
	High voltage cables not connected in firing order	Reconnect cables correctly

Engine runs but misses: An engine that runs misses runs unevenly and does not develop full power. It is some time difficult to tell by listening whether one cylinder is missing or whether the miss is intermittent and jumping around from one cylinder to another if one cylinder is missing the cause could be a defective spark plug or high voltage cable, a bad connection, and high voltage leakage across the distributor cap or through the cable insulation. In the engine the miss could be due to struck or burned valves or loss of compression resulting from broken piston rings

Condition	Possible Causes	Check or correction
Engine runs but misses	Spark plug s faulty	Clean and regap, or replace
	High voltage cables defective	Replace
	Defective coil or distributor cap or rotor faulty	Replace
	Bad connection	Clean, tighten •

	Advance mechanism defective	Check advances , repair or replace distributor
--	-----------------------------	--

Engine runs but backfires: Backfiring is a pop or bang in the exhaust manifold. It can be caused by several conditions in the ignition system. If the ignition timing is considerably off or if ignition crosses firing occurs, ignition may result before the intake valve closes. This produces a backfire. There will be a pop back through the air cleaner. Cross firing is spark jump over from one terminal to another, or from one high voltage cable to cracked or damaged cable insulation can allow spark jump over. Incorrect fuel ratio can also cause backfire.

Condition	Possible Causes	Check or correction
Engine runs but back fires:	Ignition timing off	Retime
	Ignition cross firing	Check high voltage cables, distributor' cap and rotor for leakage path
	Faulty ant backfire valve	Replace valve
	Spark plugs of wrong heat range	Install correct plugs
	Defective air-injection system	Check system
	Fuel system not supplying proper air fuel ratio	Check carburetor

Engine overheats: Most engine overheating is caused by loss of coolant through leaks in cooling system. Other causes include a loose or broken fan belt, a defective water pump, clogged water jacket in the engine, a defective radiator hose, and a defective thermostat or fan clutch. Late ignition or valve timing, lack of engine oil* over loading the engine, or high speed, high altitude or hot climate operation can cause engine overheating. Freezing of coolant can cause lack of coolant circulation, resulting in local hot spots and boiling.

Condition	Possible Causes	Check or correction
Engine overheats	Late Ignition timing	Retime
	Lack of coolant or other trouble in cooling system	Fill the coolant.
	Late valve timing or other engine conditions	Adjust for best performance.

Engine lacks power: Many conditions can cause the engine to loose power. The wrong ignition timing, or any of the conditions discussed in 4th point which cause the engine to miss, will reduce engine power. As, a restricted exhaust system can create excessive backpressure, which will prevent normal exhaust from the engine. The cylinders will retain the pressure and will not take in a full air fuel charge during the intake strokes.

Condition	Possible Causes	Check or correction
Engine lack power	Ignition timing off	Retime
	Exhaust system restricted	Clear
	Heavy engine oil	Use correct viscosity oil
	Excessive rolling resistance	Check tires, brakes, wheel bearing, alignments

Engine detonates or pings: Detonation or pinging is often blamed on the ignition system. But there are many other possible causes. In the ignition system detonation may be caused by excessively advanced ignition timing, faulty advance mechanisms and spark plugs of wrong heat range. Fuel with an octane rating too low for the engine can cause pinging or detonation. Carbon build up in the engine combustion chambers can result in detonation in two ways. First the carbon may glow or become so hot that it can become pre ignition. This can result in ping. Second the carbon builds up increases the compression ratio. This can also cause detonation.

Condition	Possible Causes	Check or correction
Engine detonation or pings	Improper timing	Time ignition *
	Wrong fuel	Use correct fuel
	Spark plugs of wrong heat range	Install correct plugs
	Carbon buildup in cylinders	Service engine

Spark plug defective: Basically, plugs that run too cold will foul, plug that run too hot with wear rapidly and burn away. This means that the plug gap increases rapidly due to the eroding effect of the spark combined with the excessive temp, of the electrodes.

Condition	Possible Causes	Check or correction
Spark plug defective	Cracked insulator	Careless installation, install new plug.
	Plug sooty	Install hotter plug, control high fuel consumption.
	Plug white or grey, with blistered insulator	Install cooler plug.

Engine diesels, or runs on: Engines with emission control require a fairly high hot idle speed for best operation. This makes run on, or dieseling, possible. Hot spots in the combustion chambers along with enough air fuel mixture getting past a slightly opened throttle valve can keep the engine running. The hot spots act as spark plug, igniting the mixture in the combustion chamber hot spots could be

from, hot spark plugs or exhaust valves or from carbon deposits in the combustion chamber. Dieseling can damage an engine.

To prevent dieseling many engines have an idle stop solenoid. It closes the throttle valve completely when the ignition switch is turned off.

Condition	Possible Causes	Check or correction
Engine diesel, or run on	Idle-stop solenoid out of adjustment or defective	Readjust , replace as necessary
	Hot spots in combustion chamber	Service engine
	Advance timing	Retime ignition

Possible causes of electronic system failure, ignition system failures can be grouped into three categories. These are

1. Loss of energy in primary circuit: This could result from:

- a. Resistance in the primary circuit due to defective lead, bad connections or ignition switch, open ignition coil primary winding.
- b. Discharged battery or defective alternator.
- c. Grounded primary circuit in ignition coil, wiring or distributor.
- d. Defective ECU or sensor coil circuit to ECU.

2. Loss of energy in the secondary circuit, due to

- a. Spark plug fouled, defective or improperly gapped.
- b. Defective high voltage wiring which allows high voltage leakage.
- c. High voltage leakage across ignition coil head, distributor cap or rotor.

3. Out of time ignition, due to:

- a. Timing not set properly.
- b. Centrifugal or vacuum advance defective.
- c. Electronic control unit {ECU} defective.

SPARK PLUG SERVICE

Spark plugs will foul or wear rapidly if they are not of the correct heat range. There are spark plug cleaners that sand blast the electrodes and porcelain tip. Then, after filling the electrodes flat, the gap can be reset if the plug is in otherwise good condition. However, with the cost of labor so high, many mechanics recommend replacing spark plugs at periodic intervals, instead of cleaning and re-gapping them. Always select and install the correct spark plugs for the engine. First, inspect and gap the plugs to the manufacturer's specification.

CONTACT-POINT SERVICE

Burned or worn contact points should be replaced. They are supplied in sets; one stationary point, one movable point on the contact arm. Some sets are supplied assembled, with an attached

condenser. Adjustment is made by turning an eccentric or by moving the stationary contact-point support.


EXPERIMENT NO 4

Objective:- Demonstration of steering system by measurement of steering Geometry angles & their impact on vehicle performance.

Theory The steering system allows the driver to guide the car along the road & turn left or right as desired. The system included the steering wheel, which the driver controls, the steering gear, which the driver change the rotary motion of the wheel into straight-line motion & the steering linkages. Most systems were manual until a few years ago. Then power steering became popular. It is now installed on about 90 percent of cars manufactured in the United State today.


Demonstration of steering system: Types of Steering System:

- i) **Pitman-arm steering gears:** Steering linkage using pitman arms are shown. The steering or at the lower end of the steering shaft consists essentially of two sports. These are a worm on the end of the steering shaft & a pitman arm shaft on which there is a gear seek a toothed roller & a stud




Front of Car

ii) **Rack & Pinion Steering Gear:** The rack & pinion steering gear has become increasingly popular for today's smaller. It is simpler, more direct acting & may be straight mechanical or power assisted in operation. A complete rack & pinion steering system, set apart from the rest of the cars. As steering wheel by shaft are turned are turned the rack moves front side to other. On large heavier vehicle, this can be a disadvantage. In a small car, rack & pinion steering is quick & easy. It provides the maximum amount of road feel as the tires meet irregularities in the road.




Front End Geometry: Front end geometry is the relationship of the angles among the front wheels, the front wheel attaching parts & the ground. The various factors that enter into front & geometry are:


- a) **FRONT SUSPENSION HEIGHT** - This is the distance from some specific point on the body, frame or suspension to the ground. If suspension is not correct it can affect the angles in the suspension system



b) CAMBER - Camber is the belting in or out of the front wheels from the vertical when viewed from the front of the vehicle. If the top of the wheels tilts out, it has positive chamber and if the top of the wheel tilts in, it has negative angle.




c) STEERING AXIS INCLINATION - It is also called ball joint inclination on vehicle that have vertical & a line drawn through the centers of the wall joints, when viewed from the front of the vehicle. Included angle = Camber + SAI.




d) CASTER - It is the angle formed by the forced or rear ward tilt of the steering axis from vertical, when viewed from the side of the wheel. The angle is positive when the steering axis tilts backwards. Reason for which, caster is used:\

1. To maintain directional stability & control.
2. To increase steering return ability.
3. To reduce steering effort..



Caster of the left-front wheel as viewed from the driver's seat. The view is from the inside so that the backward tilt of the steering axis from the vertical can be seen. This backward tilt, is called *positive caster*.


IDLER ARM



e) **TOE** - It is the amount in inches, millimeters or degrees in which the front wheels point inward or outward. Its purpose is to stabilize steering & to prevent side-slipping & successive wear of the tyres.

Toe-in. The wheels are viewed from above, with the front of the car at the top of the illustration distance A is less than distance B .

f) **TURNING RADIUS** - It is sometimes called toe-out during turns and turning angle. It is the difference between the two angles formed by the two front wheels and the car during turn.



Turning radius, or toe-out on turns

g) STEERING RATIO - One of the jobs of steering gear is to provide mechanical advantages. In a machine or mechanical device, this is the force supplied to it. The steering ratio is the number of degrees that the steering wheels must be turned to pivot the front wheels. Actual steering ratio varies, greatly, depending on the type of operation. Steering ratio called fast or quick steering, require much less Steering heel movement to produce the desired steering effort. Steering ratio is determined by two factors. Steering linkage ratio & the gear ratio of the steering effort. In a rack & pinion steering system, the steering ratio is determined, largely by the diameter of the pinion gear. The smaller the pinion the higher the steering ratio. However there is a limit to how small the pinion can be made.


EXPERIMENT NO 5

Objective-Trouble shooting in braking system with specific reference to master cylinder, brake shoes, overhauling of system and the adjusting of the system and its testing

Theory

The construction and operation of the various types of braking system used in automotive vehicles. The braking system used most frequently operates hydraulically, by pressure applied through a liquid. These are the foot-operated brakes that the driver normally uses to slow or stop the car. They are called the service brakes. In addition, all cars have a parking-brake system, which is mechanically operated by a separate foot or hand lever. On some trucks and buses, the braking system is operated by air pressure. This type of brake is an air brake.

Diagram



DRUM BRAKE TROUBLE DIAGNOSIS

Brake pedal goes to the floor: When the brake pedal goes to the floor, there is no pedal reserve. Full pedal travel does not produce adequate braking. One section might fail, but it would be rare for both to fail at the same time. It is possible that the driver has continued to operate the vehicle with one section out (either the driver may have ignored the warning light, or the pressure differential valve or the light may have failed). Causes worn linings, air in the of failure could be linkage or brake shoes out of adjustment, 3 system, lack of brake fluid, or a defective master cylinder

Complaint	Possible Cause	Check or Correction
-----------	----------------	---------------------

Brake pedal goes to floorboard	Linkage or shoes out of adjustment	Adjust
	Brake linings worn	Replace
	Lack of brake fluid	Add fluid; bleed system
	Air in system	Add fluid; bleed system
	Worn master cylinder	Repair

One brake drags: If one brake drags, this means that the brake shoes are not moving away from the brake drum when the brakes are released. This trouble could be caused by incorrect shoe adjustment, or by a clogged brake line, which does not release pressure from the wheel cylinder. It could also be due to sticking pistons in the wheel cylinder, to weak or broken brake-shoe return springs, or to loose wheel bearings. Loose wheel bearings could permit the wheel to wobble so that the brake drum comes in contact with the brake shoes even though they are retracted

Complaint	Possible Cause	Check or Correction
One brake drags	Shoes out of adjustment	Adjust
	Clogged brake line	Clear or Replace line
	Wheel cylinder defective	Repair or replace
	Weak or broken return spring	Replace
	Loose wheel bearing	Adjust bearing

All brakes drag: When all the brakes drag, the brake pedal may not have sufficient free travel. Then the pistons in the master cylinder do not fully retract. This would prevent the lip of the piston cup from clearing the compensating port & hydraulic pressure would not be relieved, as it should be. As a result, the wheel cylinders would not allow the shoes to retract.

A similar condition could result if engine oil was added to the system. Engine oil- will cause the piston cups to swell. If they swelled enough, they would not clear the compensating ports even with the piston in the "fully retracted" position. A clogged compensating port would have the same result. Do not use a wire or drill to clear the port. This might produce a burr that would cut the piston cup. Instead, the port should be cleared with alcohol & compressed air.

Clogging of the reservoir vent might also cause dragging brakes by pressurizing the fluid in the reservoir. This prevents release of pressure on the fluid in the lines. A clogged vent could also cause leakage of air into the system

Complaint	Possible causes	Check or correction
All brake drags	Incorrect linkage adjustment	Adjust
	Trouble in master cylinder	Repair or replace
	Mineral oil in system	Replace damaged parts

Car pulls to one side: If the car pulls to one side when the brakes are applied, more braking force is being applied on one side than to the other. In a front engine rear wheel drive car, linings will become soaked with oil if the lubrication level in the rear axle is too high this may cause leakage past the oil seal. At the front wheels, brake linings may get grease on them. If the front wheel bearings are over lubricated or if the grease seal is defective or improperly installed. Wheel cylinder will leak brake fluid onto the brake linings, if the cups are defective, if the cylinder bore is pitted, or if an activating pin has been improperly installed. If the linings at the left wheel become soaked with brake fluid or oil, the car pulls to the left because the brakes are more effective on the car's left side. However, the direction of pull may depend on the type of friction material & the contaminant.

Complaint	Possible causes	Check or correction
Car pull to one side	Brake line clogged	Clear or replace line
	Defective -wheel cylinder	Repair or replace
	Brake backing plate loose	Tighten
	Mismatched linings	Use same linings all around


Soft or Spongy pedal: If the pedal action is soft or spongy, there is, probably, air in the hydraulic system. Out of adjustment brake shoes could also cause this. Conditions that could allow air to enter the hydraulic system are described

Complaint	Possible Cause	Check or Correction
Softy or spongy pedal	Air in system	Add brake fluid; bleed system
	Brake shoes out of adjustment	Adjust

Poor braking action (requiring excessive pedal force): A need for excessive pedal force could be caused by improper brake shoe adjustment. The use of wrong brake lining could cause the same trouble. Sometimes, brake linings that have become wet after a hard rain or after driving through water will not provide sufficient friction against the drums. However, normal braking action is usually restored after the brake linings have dried.


Another possible cause of poor braking action is excessive temperature. After the brakes have been applied for long period as in coming down on long hill, they begin to overheat. This overheating reduces braking effectiveness so that the brakes "fade". Often if the brakes are allowed to cool, braking efficiency is restored. However, excessive long period braking at high temperature. May char the brake linings so that they must be replaced. Further, this overheating may glaze this brake drum so that it becomes too smooth for effective braking action. Then the drum must be ground or turned to remove the glaze. Glazing can also take place even though the brakes are not overheated. Failure of the power brake assembly will noticeably increase the force on the foot pedal required to produce braking.

Brake too sensitive or Grab: If linings are greasy or soaked with oil or brake fluid, the brakes tend to grab with slight pedal force. Then the linings must be replaced. If the brake shoes are out of adjustment, grabbing may result. A loose backing plate may cause the same condition. As the linings contact the drum, the backing plate shifts to give hard braking. A defective power brake booster can also cause grabbing.



Noisy brakes: Brakes become noisy, if the brake linings wear so much that the rivets contact the brake drum, if the shoes become warped so that the contact with the drum is not uniform, if the drum becomes rough & noisy worn. Any of these conditions may cause a squeak or squeal when the brakes are applied. Loose parts, such as the brake backing plate, also may rattle.

Air in the system: If air gets into the hydraulic system, poor braking & spongy pedal will result. Air can get into the system if the air vent in the master cylinder cover or cap becomes plugged. This may tend to create a partial vacuum in the system on the return stroke of the piston. Air could then by-pass the rear piston cup & enters the system. Always check the vent & clean it when the cap or cover is removed. Air can also get into hydraulic system if the master cylinder residual checks valve is leaky & does not maintain a slight pressure in the system. A leak could allow air to seep in around the wheel-cylinder piston cups. Without residual line pressure in the system there would be no pressure holding the cups tight against the cylinder valves.



Probably, the most common cause of air in the brake system is insufficient brake fluid in the master cylinder, if the brake fluid drops below the compensating port, the hydraulic system will draw air in as the piston moves forward when braking. Air in the system must be removed by adding brake fluid & bleeding the system. _____

Loss of brake fluid: Brake fluid can be lost if master cylinder leaks, if the wheel cylinder leaks, if the line connections are loose, if the line is damaged. One possible cause of the wheel cylinder leakage or there is incorrect installation of actuating pin. If the pin is cocked, the side thrust on the piston may permit leakage past the piston. Leakage from other causes at the master cylinder or wheel cylinder requires removal & repair or replacement of the defective parts.

Complaint	Possible Cause	Check or Correction
Loss of brake fluid	Master cylinder leaks	Repair or replace
	Wheel cylinder leaks	Repair or replace
	Loose connection, damaged tube	Tighten connections; replace tube


Brakes do not self-adjust: Brakes do not self adjust if the self-adjusted mechanism has been removed, or if the adjustment screw is stuck, or if the adjustment lever does not engage the star wheel, or if the adjuster was incorrectly installed.

Warning light comes on when braking: If the warning light comes on when braking, it means that there is low pressure in one section of the hydraulic system. One of the two braking sections has failed. Both sections should be checked so that the trouble can be found & eliminated. It is dangerous to drive in this condition. Even though the car slows, only half the wheels are being braked.


BRAKE TESTING & SERVICE

Brake testers: There are two types of brake testers - the static & the dynamic. One type of static tester has four tread plates & registering columns. To make the tests, the car is driven onto the tread plates at a specified speed & the brakes are applied hard. The stopping force at each wheel is registered on the four columns. -If the readings are too low or are unequal, brake service is needed.

The dynamic brake tester has rollers in the floor. The two wheels, whose brakes are to be tested, are placed on the rollers. If these are the drive wheels, the wheels are spun at the specified speed by the vehicle engine, or otherwise, the wheels are spun by an electric motor. Then the throttle is released or the electric motor is turned off and the brakes are applied. The braking force at each wheel registers on meters. This shows if the brakes perform normally or if they need service.




Platform type brake tester



Dynamic Brake Tester

Replacing drum brake shoes: When linings wear, the brake shoes must be replaced. To replace the shoe in a drum brake, the wheel & brake drum must be removed. Then shoes with new linings are installed. Although been a practice years ago, brake shoes are relined at few locations even today.

Until a few years ago, most relined shoes were "arced". This meant the shoes were ground slightly to better fit the larger diameter of a used or refinished brake drum. However, grinding brake shoe is no longer universally recommended. This is because of the hazards, resulting from the asbestos dust created during shoe grinding.



Servicing brake & drums: Brake disk requires replacement only if they become deeply scored or are warped out of line. Light scores or grooving are normal & will not affect braking. Some manufacturers recommend never grinding or refacing a scored brake disk. Instead, installation of a new disk is recommended. Refer to the manufacturer's service manual for the proper procedure to follow & tools to use.

Brake disks have a discard dimension (a number) cast into them. This dimension is the minimum thickness to which the disk can be refinished. If the disk must be refinished to a thinner diameter, discard it. The disk is too thin for safe use.

On drum brakes, the drum should be inspected for distortion, cracks, scores, roughness or excessive glaze or smoothness. Glaze lowers friction & braking* efficiency. Drums that are distorted or cracked should be discarded & new drums installed. Light score marks can be removed with fine emery cloth. All traces of emery must be removed after smoothing the drum. Deeper scores, roughness & glaze can be removed by turning or grinding the drum. Many brake drums have their discard diameter cast into them. This dimension is the maximum allowable diameter. If it is necessary to turn or grind the drum to a larger diameter, discard it. The drum would be too thin for safe use. Brake drums should not be refinished to larger than the original diameter by more than 0.060" (1.5mm). This leaves 0.030" (0.76mm) left for wear before the discard diameter is reached.

The diameters of left & right drums on the same axle should be within 0.010" (0.25mm) of each other. When the drum diameters on the same axle vary more, than this, replace both drums.

Wheel cylinder service: Most wheel cylinders can be disassembled & rebuilt on the car. However, many manufacturers recommend that the wheel cylinder be removed from the backing plate & serviced on the bench. This makes it easier to properly & thoroughly clean, inspect & reassemble the cylinder.

To remove a wheel cylinder from the car, first remove the wheel & brake drum. Then disconnect the brake hose or tube from the wheel cylinder. Remove the wheel cylinder by taking out the attachment bolts or retainer. Then tape the end of the hose or pipe shut to prevent any dirt from getting in. Disassemble the wheel cylinder by first pulling off the boots. Then push out the piston cups & springs. Clean all wheel cylinder parts in clean brake fluid. Dry the parts with compressed air. Then place the dried parts on clean lint free shop towels or paper. Check that all passages in the wheel cylinder & bleeder screws are clear by blowing through them with compressed air.

Inspect the cylinder bore for scoring & corrosion. Use crocus cloth to remove light corrosion & strains. Replace the wheel cylinder if crocus cloth does not remove the corrosion, or if the bore is pitted or scored. Some manufacturers permit the use of brake cylinder hone to remove scores & rust. However, the cylinder bore must not be honed more than 0.003" (0.08mm) larger than its original diameter. If the scores do not clean out, replace the cylinder. The wheel cylinder also should be replaced if the clearance between the cylinder's bore & the piston is excessive.

When reassembling the wheel, cylinder, lubricate all parts with clean brake oil. Then assemble the wheel cylinder, using all parts in the repair kit. Install the bleeder screw & torque it to specifications.


Master cylinder service: Master cylinder may require disassembly for replacement of internal parts. However, some technicians prefer to install a new or rebuilt cylinder. The service procedures for master cylinder used with disk brakes & drum brakes are very similar. One difference is that with disk brakes a larger brake fluid reservoir is required. With a braking system that has front wheel disk brakes & rear wheel drum brakes. Note that the fluid reservoir for the front disk brakes is larger than the other. To service the master cylinder, clean the outside. Then remove the master cylinder from the car. If the car has a manual brake system, slide the boot to the rear, remove the retainer clip & then remove the retainer, push rod & boot. Use the push rod to force the primary piston inward & remove the snap ring from the groove in the piston bore. Then remove the primary piston assembly. The repair kit contains a complete new primary piston assembly.

Remove the secondary piston stop screw, if so equipped. Using the shop air hose apply slight air pressure through the compensating port at the bottom of the reservoir. This will force out the secondary piston assembly. Remove the piston seals from the secondary piston

The outer tube seats, check valves & springs must not be removed from some master cylinders. They are permanent parts of the master cylinder. However, these parts may be removed from other master cylinder. Follow the procedure in the manufacturer's service manual. Most disk brakes hydraulic systems do not have check valves. Clean all parts in brake fluid or brake cleaning solvent only. Blow dry with filtered compressed air Blow out all passages & ports to be sure they are clear If the master cylinder is scored, corroded, pitted, cracked, porous or scoring are deep; a new master cylinder must be installed.

To assemble the master cylinder, dip all parts (except the body) into the brake fluid. Insert the complete secondary piston assembly, with return spring, into the master cylinder bore. Install the secondary piston stop screw if so equipped. Put the primary piston assembly into the bore Depress the primary piston & install the snap ring in the bore groove. Install the push rod, boot & the retainer on the push rod, if so equipped. Install the push rod assembly into the primary piston make sure the retainer is properly seated & holding the push rod securely

Hydraulic brake tubing repair: Most hydraulic brake tubing is made of double-walled, welded steel tubing, which is coated to resist rust. Only the tubing specified by the automotive manufacturer should be used. When replacing a tube, used the old tube as a pattern to form a new tube. Do not kink the tubing or make sharp bends. Brake tubing must be cut off square with a special tube cutter. Do not use a jaw type cutter or a hacksaw to cut brake tubing. Either of these can distort the tubing & leave heavy burrs that would prevent normal flaring of the tube. After the tube has been cut off, a flaring tool must be used to double flare the end of the tube.




Flushing Hydraulic: The process of removing all the old brake fluid from hydraulic system is called flushing. Some car manufacturers recommend flushing the hydraulic system when new parts are installed in it. The system must be flushed if there is any indication of brake fluid contamination. Signs of contaminated brake fluid include corroded metal parts and soft or swollen rubber parts. To flush the hydraulic system install the pressure bleeder on the master cylinder. If the car has metering valve, it must be held in the open position. Place the brake bleeder wrench on the bleeder valve in the wheel cylinder or caliper nearest the master cylinder. Install one end of a short bleeder hose on the bleeder valve. Place the other end in a transparent container.

Open the bleeder valve about 1/4 turns & let the fluid drain into the container. Close the bleeder valve when the fluid appears clean & clear. Then move on to the bleeder valve next closest to the master cylinder. Repeat the procedure at each wheel. When flushing is completed, check that the master cylinder is filled. About 1 quart (0.946L) of clean, fresh brake fluid is needed to flush the hydraulic system. If the hydraulic system is being flushed because of fluid contamination, replace all rubber parts in the master cylinder, wheel cylinders & calipers, brake hoses & combination valve. Then bleed the hydraulic system.

Some manufacturers recommend the use of special flushing fluid. This fluid is used instead of new brake fluid during the flushing operation. Flushing is continued until all the old brake fluid has been flushed out. Then the flushing fluid is purged by applying clean dry air through the master cylinder to blow the fluid out. Do not use too much air pressure. After all flushing fluid is out, fill the master cylinder reservoir with new brake fluid. Then bleed the system as explained below.

Filling & bleeding hydraulic system: After flushing the hydraulic system or at any time, air may be in the hydraulic system. The hydraulic system must be filled and bled. For the brakes to operate properly all air must be removed from the system.

The process of getting rid of any air trapped into the system line or component is called bleeding. In the bleeding process, brake fluid is forced through the brake line or component that has air in it. To bleed the brakes, install the pressure bleeder on the master cylinder. If the vehicle has a metering valve, it must be held in the open position. Place the bleeder wrench on the bleeder valve in the wheel cylinder or caliper nearest the master cylinder. Install one end of the bleeder hose on the bleeder valve. The lower end of the bleeder hose is immersed in a clear container partly filled with fresh brake fluid. This allows you to see any air bubbles that come out of the line; it also prevents any air from being pulled back into the line. This can happen if the pressure on the brake fluid is released before the bleeder valve is closed.




If the master cylinder has bleeder valve and open it about 1/4 turn Watch the flow of brake fluid from the end of the hose. As soon as the bubbles stop & brake fluid flows from the hose in a solid stream, close the bleeder valve. Repeat these steps at each wheel. Then disconnect the pressure bleeder from the master cylinder. Check that the master cylinder is filled with brake fluid. Wipe up any spilled brake fluid. Install the master cylinder. Cover the seal & cover. Pump the brake pedal several times. Be sure that the firm brake pedal is obtained before moving the vehicle.

EXPERIMENT NO 6

OBJECTIVE: Fault diagnosis in transmission system including clutches, gear box assembly & differential.

Purpose of clutches: The clutch is used in cars with transmission that are shifted by hand. It allows the drive to couple/uncouple the engine from the, transmission. Power flows from the engine, through the clutch, to the transmission & power train.

Diagram**FAULT DIAGNOSIS-**

1) Clutch slips while engaged: The slipping clutch generates excessive heat & may burn causes may be incorrectly linkage of pedal. Readjusting the linkage may correct the problem. Binding linkage or a broken return spring may prevent full return of the linkage to the engaged position. If none of the above is causing the slippage then remove the clutch for service.

The recommendation of most manufacturers is it replaces the disk & pressure plate assembly if there is internal wear or 'damage or weak springs. Pressure plate assemblies can be rebuilt, but this usually is a job for clutch rebuilder.

2) Clutch chatters or Grabs when Engaged- Check the clutch linkage for binding It is binds could release suddenly to throw the clutch into quick engagement with a resulting heavy jerk. A broken engine mount can also cause chattering because the engine is free to move excessively. Inside the clutch, the trouble could be due to oil or grease on the disk facings or to glazed or loose facings

Complaint	Possible Cause	Check or correction
Clutch chatters or grabs when engaged	Oil or grease on disk facings or glazed or loose facings	Replace facings or disks
	Binding of friction-disk hub on clutch shaft	Clean and lubricate Splines replace defective parts
	Binding in clutch-release Linkage	Free, adjust, and lubricate
	Broken engine mount	Replace
	Warped clutch disk	Replace

3) Clutch spins or drags when disengaged- The first check is pedal linkages adjustment if there is excessive pedal lash or free travel, even full movement of the pedal will not release the clutch faulty. One cause of loose friction disk facings is abuse of the clutch. This abuse includes "popping" the clutch for a quick gateway (letting the clutch out suddenly with the engine turning at high rpm) slipping the, clutch for drag strip starts & modifying the engine for increased power output

Complaint	Possible Cause	Check or correction
Clutch spins or drags when disengaged	Possible Cause pedal-linkage Incorrect adjustment	Readjust
	Wrapped friction disk or pressure plate	Replace defective parts
	Loose friction-disk facing Broken engine mount	Replace, defective parts
	Improper release-lever adjustment	Readjust

4) Clutch Noise- It is noticeable when the engine is idling. Noise is heard when the clutch is either engaged or disengaged or during pedal movement. Noises heard while the pedal is in motion are probably due to dry/dirty linkage pivot points. Noise heard when the transmission is in neutral but disappear when the pedal is depressed are transmission noises. Noise heard while the clutch is engaged could be due to a friction on disk hub i.e. loose on clutch shaft or perhaps both it both are excessively worn.


5) Clutch Pedal Pulsates- Noticeable when a slight force is applied to the clutch pedal with the engine running. Pulsations can be felt by the foot as a series of slight pedal movements & ceases when

the pedal force is increased. This condition often indicates troubles that must be corrected before serious damage to the clutch results.

6) Friction Disk Facings Wear Rapidly- Caused by the friction between slippage facings & the flywheel or pressure plate. If the driver has the habit of "riding" the clutch by resting the left foot on the pedal, part of the pressure plate spring force will be taken up so that slippage may take place. Likewise, frequently use of the clutch, incorrect clutching & declutching, overloading the clutch, & slow clutch engagement & disengagements increase clutch facing wear

Part B

Function of differential A differential is required to compensate for the difference in distance that the drive wheels travel when the car rounds a curve. If a right angle turn were made with the inner rear wheel turning on a 20 foot(6.1 m) radius, the inner rear wheel would travel about 31 feet (9.5m) while the outer rear wheel would travel about 39 feet (12m). The differential permits power flow to both drive wheels, while allowing the wheels to turn different distance, when the car is rounding a curve.



Operation of differential: When the car is on a straight road, the ring gear, differential case, differential pinion gears, and two differential side gears all turn as a unit. The two differential pinion gears do not rotate on the pinion shaft. This is because they exert equal force on the two differential side gears. As a result, the side gears turn at the same speed as the ring gear, which causes both drive wheels to turn at the same speed also.

Differential trouble diagnosis- Humming: A humming noise is often caused by incorrect internal adjustment of the drive pinion or the ring gear. Incorrect adjustments prevent normal tooth contact and can cause rapid tooth wear and early failure of the differential.

Noise on acceleration: Noise that is louder when the car is accelerating probably means there is heavy contact on the heel ends of the gear teeth. Noise that is louder when the car is coasting probably means there is heavy toe contact.


Noise on curves: Noise that is heard only when the car is going around a curve the trouble is inside the differential case. They can also be due to defective axle bearing. During a turn, the outside bearing takes an increased load.

Limited slip differential: It requires a special type of lubricant. Wrong lubricant can cause the clutch surfaces to grab. Remedy is to replace the old lubricant with the right one.

Part-C

GEAR BOX

It is an assembly of gears and shafts that transmit power from the engine to the drive axle. The transmission allows the engine crankshaft to turn fast while the wheels turn slowly. The transmission can then change the ratio of crankshaft speed to the car speed as car speed increases. Therefore, with a three-speed transmission, the engine crankshaft may turn about four, eight, or twelve times for each wheel revolution. In addition, the transmission includes a reverse gear so that the car can be backed. The driver selects each of these gear ratios manually.



Fault diagnosis in gear box

Complaint	Possible cause	Check or correction
Hard shifting into gears	<ul style="list-style-type: none"> a. Gearshift linkage out of adjustment b. Gearshift linkage needs lubrication c. Clutch not disengaging d. Excessive clutch-pedal free play e. Shifter fork bent f. Sliding gears or synchronizer tight on shaft splines g. Gear teeth battered h. Synchronizing unit damaged or springs improperly installed i. Shifter tube binding in steering column j. End of transmission input shaft binding in crankshaft pilot bushing 	<ul style="list-style-type: none"> Adjust Lubricate Adjust Adjust Replace or straighten Replace defective parts Replace defective gears Replace unit or defective parts; install springs properly Correct tube alignment Lubricate; replace bushing
Transmission sticks in gear	<ul style="list-style-type: none"> a. Gearshift linkage out of adjustment or disconnected b. Gearshift linkage needs lubrication c. Clutch not disengaging d. Detent balls (lockouts) stuck e. Synchronizing unit stuck f. Incorrect or insufficient lubricant in transmission g. Internal shifter component damaged 	<ul style="list-style-type: none"> Adjust; reconnect Lubricate Adjust Free; lubricate Free; replace damaged parts Replace with correct lubricant and correct amount Remove transmission to inspect and service shifter parts
Transmission slip out of gears	<ul style="list-style-type: none"> a. Gearshift linkage out of adjustment or disconnect b. On floor shift, shift boot stiff or shift-lever binding c. Weak lockout springs d. Bearings or gears worn e. End play of shaft or gears excessive f. Synchronizer worn or defective g. Transmission loose on clutch housing misaligned h. Clutch housing misaligned i. Pilot bushing in crankshaft loose or 	<ul style="list-style-type: none"> Adjust Replace boot; adjust console to relieve binding Replace Replace Replace worn or loose parts Repair; replace Tighten mounting bolts; correct alignment


	<ul style="list-style-type: none"> misaligned j. Input-shaft retainer loose or broken k. Broken engine mount 	<ul style="list-style-type: none"> Correct alignment Replace Replace Replace
No power through transmission	<ul style="list-style-type: none"> a. Clutch slipping b. Gear teeth stripped c. Shifter fork or other linkage part broken d. Gear or shaft broken e. Drive key or spline sheared off 	<ul style="list-style-type: none"> Adjust Replace gears Replace Replace Replace
Transmission noisy in neutral	<ul style="list-style-type: none"> a. Gear worn or tooth broken or chipped b. Bearings worn or dry c. Input-shaft bearing defective d. Pilot bushing worn or loose in crank-shaft e. Transmission misaligned with engine f. Countershaft worn or bent, or thrust plate or washers damaged 	<ul style="list-style-type: none"> Replace gears Replace; lubricant Replace Replace Realign Replace worn or damaged parts
Transmission noisy in gear	<ul style="list-style-type: none"> a. Clutch friction disk defective b. Incorrect or insufficient lubricant c. Rear main bearing worn or dry d. Gears loose on main shaft e. Synchronizers worn or damaged f. Speedometer gears worn 	<ul style="list-style-type: none"> Replace Replace with proper amount of correct lubricant Replace or lubricate Replace worn parts Replace worn or damaged parts Replace
Gears clash during shifting	<ul style="list-style-type: none"> a. Synchronizer defective b. Clutch not disengaging; pedal free play incorrect c. Hydraulic system (Hydraulic clutch) defective d. Idle speed excessive e. Pilot bushing binding f. Gearshift linkage out of adjustment g. Lubricant incorrect 	<ul style="list-style-type: none"> Repair or replace Adjust Check cylinder, add fluid, et Readjust Replace Adjust Replace with correct lubrica
Transmission noisy in reverse	<ul style="list-style-type: none"> a. Reverse idler gear or bushing worn or damaged b. Reverse gear on main shaft worn or damaged c. Counter gear worn or damaged 	<ul style="list-style-type: none"> Replace Replace Replace

	d. Shift mechanism damaged	Repair, replace defective parts.
Oil leaks	<ul style="list-style-type: none"> a. Foaming due to incorrect lubricant b. Oil level too high c. Gaskets broken or missing d. Oil seals damaged or missing e. Oil slingers damaged, improperly installed, or missing f. Drain plug loose g. Transmission retainer bolts loose h. Transmission or extension case cracked i. Speedometer-gear retainer loose j. Side cover loose k. Extension-housing seal worn or driveline yoke worn 	<ul style="list-style-type: none"> Replace with correct lubricant Use proper amount, no more Replace Replace Replace correctly Tighten Tighten Replace Tighten Tighten Replace

EXPERIMENT NO 7

OBJECTIVE: - Replacing-of ring and studying the method of replacing piston after repair

Theory:-The pistons are slightly smaller; there is a gap, or clearance, between the piston and the cylinder. This gap must be filled. Otherwise, some of the compressed air-fuel mixture would leak out through the clearance. Also, when combustion took place, much of the high-pressure gas would leak out. These leaks would greatly reduce the efficiency of the engine. Much of the power would be lost. To prevent this piston rings are installed on the pistons.



From a sliding seal between the piston and the cylinder wall. These are called compression rings.


Scrape off most of the oil that is splashed on the wall so that it does not get up into the combustion chamber where it would burn. These are called oil control rings

Piston Ring Service: When an engine is disassembled for service, the old piston rings should not be reinstalled. Rings that have been used, even for very short time, usually will not reset properly. Selection of new piston rings depends on the condition of the cylinder walls and how they are to be reconditioned. If the cylinder walls are only slightly tapered or out of round, then the new standard rings selected for an engine may depend on the cylinder reconditioning procedure that has been used.

Automotive manufacturers generally recommend refinishing the cylinder walls before piston ring installation to "Break the Glaze". Cylinder walls take on a hard, smooth glaze after the engine has been running. In many automotive shops, this glaze is removed by running a glaze breaker up and down the cylinder a few times before installing new rings. The glaze is a good anti-cuff surface and will not retard the seating of certain type new rings. However, the cylinder walls must be reasonably round and in good condition. When a cylinder is honed, the proper honing job leaves a Crosshatch pattern on the cylinder


walls. The hone marks should intersect at about a 60-degree angle. This leaves the surface needed for oil retention and quick seating of new rings.

Fitting Piston Rings: Piston rings must be fitted to the cylinder and to the rings grooves in the piston. Rings come in packaged sets in graduated sizes to fit various sizes of cylinders. Most packages include instructions that describe how to install the rings. Follow these instructions carefully:




As a first step, the rings should be pushed down into the cylinder with a piston, and the ring gap measured. The ring gap is the space between the ends of the rings. It is measured with a thickness gauge. Figure shows the gap being measured with ring pushed down to the lower limit of ring travel. If the cylinder is worn, that is where the ring gap will be smallest. If you may have the wrong ring set for the engine, you may have incorrectly measured cylinder diameter, or the wrong rings may have been packaged in the box. Typical piston ring end gap in an automotive engine is from 0.010 to 0.020 inch [0.25 to 0.51 mm].

If the cylinder is tapered, the diameter at the lower limit of the ring travel (in the cylinder) will be smaller than the diameter at the top. Therefore, the ring must be fitted to the diameter at the lower limit of ring travel. If it is fitted to the upper part of the cylinder, the ring gap will not be great enough at the lower limit of the ring travel. As a result, the ring ends will touch together. The ring will be broken, and the cylinder wall will be scored. Always measure the ring gap with ring pushed down to its minimum diameter at the lower limit of ring travel. The clearance should be wide enough so that the ring ends do not butt together at normal engine temperatures



Checking the lit oil the piston ring in the ring-groove



If ring gap correct, insert the outside surface of the ring into the proper ring groove in the piston (see in fig). Then roll ring around in the groove to make sure the ring has a free fit around the entire piston. An excessively tight fit probably means that the ring groove is dirty. Another possibility is that the ring groove has been nicked or burred with the blade of ring groove cleaner. Some companies recommend using the end of a broken ring, which has been filed to a sharp edge to clean the ring grooves. Some technicians prefer this because the piece of the ring will not cause nicks or burrs



Install the rings in the ring grooves, using a piston ring expander. Then measure the piston-ring side clearance. The clearance should be least 0.001 inch [0.025 mm] and not more than 0.004 inch [0.10 mm] for most engines.

Cautions on installing Piston Rings: The three-part oil rings are installed one part at a time' various types of compression rings and their proper installed positions are shown in fig. Never spiral the compression rings into the grooves. (Spiraling the rails of an oil ring is shown in fig). This could bend or break the compression ring and cause loss of compression and blow by. Instead, always install compression rings with a piston-ring expander. Never over-expand compression rings while installing them. They may break piston rings installed upside down may cause excessive oil consumption.


The piston rings must be fitted to the ring grooves in the piston and also to cylinder. If you are fitting rings to a tapered cylinder, check the ring end gap at the lower limit of ring travel.

PISTON:-

Theory

Pistons are usually made of aluminum alloy, which is a mixture of aluminum and other metals. Automotive pistons weigh about 1 pound (0.454 kg) they are a sliding fit in the cylinders. This means the pistons can slide up and down in the cylinders. This means the pistons are slightly smaller in diameter than the cylinders.

Diagram




Piston Service: After the piston and rod assemblies are removed from the engine, the pistons and rods should be separated. Then the rings can be removed from the pistons. The rings can also be removed from the pistons before the pistons and rods are separated. A piston-ring expander can be used for ring removal. The tool has two small tangs that catch under the ends of ring. When force is applied to the tool handles, the ring is opened slightly so it can be lifted out of the ring groove and off the piston. Install new rings during an engine overhaul. Once the ring break-in coating and tool marks are worn off, the ring will not reset itself if it is reinstalled.

Piston Cleaning: Remove carbon and varnish carefully from piston surfaces. Do not use a caustic cleaning solution or wire brush. These could damage the piston-skirt finish. You may decide to re-install the pistons in the engine. Therefore, do not damage them. Use the cleaning method provided in your shop to clean the pistons. Clean ring grooves with a clean-out tool. You can also use the end of a broken piston ring filed to a sharp edge. Oil-ring slots, or holes, must be clean so that oil can drain back from them. Use a drill of the proper size. Do not remove the metal when cleaning the slots or holes.

Piston Inspection: Examine the pistons carefully for wear, scuffs, scored skirts, worn ring grooves, and cracks. Look for cracks at the ring lands, skirts, pin bosses, and heads. Any defects require replacement of the piston, with these exceptions: cutting the grooves larger and using ring-groove spacers can sometimes

repair Worn ring grooves. Piston-skirt wear or collapse (reduction in skirt diameter) can sometimes be corrected by knurling the piston skirt.




Using a micrometer to measure piston diameter

Check the fit of piston pins in the pistons or piston bushings. One-way of doing this is to use a small-hole gauge to check the piston-bushing bores, and a micrometer to measure the pin diameter. On the type of piston without a bushing in which the oscillates, the piston and pin are supplied in matched sets. If the fit is too loose, or there are other pin or piston defects, the pin and piston are replaced as a matched set. The piston-pin clearance should be no greater than 0.001 inch [0.025 mm].

Measure the size of each piston with a micrometer. The measurement should be made on the piston skirt 90 degrees from the piston pin, and 6-mm below the bottom of the oil-ring groove. This is called the sizing point. Compare the piston measurement made at the sizing point with the cylinder diameter. This measurement may be made with a telescope gauge and micrometer, a cylinder-bore gauge, or an inside micrometer. If the cylinder wall is excessively worn or tapered, it will require refinishing. When the cylinder is refinished, then a new oversize piston must be installed.

On some engines, the manufacturer recommends fitting the pistons by using a long thickness gauge and the piston (upside down) in the cylinder. Use a 0.0025-inch [0.06 mm] thickness gauge for used pistons, and a 0.002 inch [0.05 mm] thickness gauge for new pistons. With the bottom of the piston skirt about 1 inch [25 mm] below the top of the block, the piston should hang (not fall free) on the thickness gauge. If the piston falls through the bore, the piston is too small for the cylinder.

Ring-Groove Repair: If a piston is in good condition except for excessive ring groove wear, the groove can be repaired in some pistons. The top ring groove is the groove that wears the most. During engine overhaul, many pistons will be found with excessively worn top ring grooves. The ring groove may be checked with a wear gauge. If the ring groove is worn 0.006 inch [0.15 mm] or more, it can be machined to a larger width with a special hand-operated lathe. This squares up the top and bottom sides of the ring groove. Then the new piston ring is installed with a spacer.



Piston Resizing: automotive manufacturers do not recommend Resizing of collapsed or worn pistons. Excessive resizing can weaken the piston. One piston-reconditioning procedure for older piston is knurling. The piston skirt is run between a supporting wheels and a knurling tool. This displaces metal, which expands the diameter of the piston skirt. The indentations from little pockets that can hold lubricating oil to reduce scuffing.

Selecting New Pistons: New pistons are ready for assembly and installation when they are removed from the box. They are available in various sizes for each engine, usually known as "Standard Oversize". When oversize pistons are used, the cylinders are rebored and then finished to fit the pistons. Engine manufacturers supply oversize piston of the same weight as the original pistons. This eliminates any balance problem with the engine when different size pistons are installed. Some engine repairs may require the reboring of only one or two cylinders. When this is done, maximum cylinder-size difference should not exceed 0.010inch [0.25 mm].

Aluminum pistons are usually supplied with new piston pins already fitted and packaged in the same box. This ensures the proper clearance between the pin and the pin bore in the piston. New pistons have a special finish to prevent scuffing during initial start-up. They must not be buffed with a wire wheel. This would remove the finish and increase the chances of scuffing during break-in.

Fitting Piston Pins in Pistons: On pistons with piston-pin bushings, worn bushings may be replaced. The new bushings are honed to size to fit the piston pins. Piston-pin clearance should be no greater than 0.001 inch [0.025 mm]. Aluminum pistons are supplied with prefitted piston pins as a matched set. If a pin set is required. However, some automotive machine shops hone the piston-pin otherwise in good condition. Most engine manufacturers do not recommend this.

Rod-And-Piston Alignment: After the rod and piston have been reassembled, but before the rings are installed on the piston, alignment should be checked with a rod aligner. A V block is held against the piston. If the V block does not line up with the faceplate as the piston is swung across it, the connecting rod is bent or twisted. Some connecting rods can be straightened. Check with the manufacturer's service manual before reusing a straightened connecting rod